

SKI WRAP INSTALLATION

Materials & Tools Needed before installing YourBoardWrap

- Denatured or rubbing alcohol mixed with water. You will need equal parts of water and alcohol. 50/50
- Blow Dryer • A Squeegee (That is provided with YourBoardWrap.com purchase) • Window Cleaner
- Single edge razor blade (An exacto blade is easier to use if you have one.) • 2" masking tape (for hinge)

Prepping Your Skis

Pull off any stickers with the heat of a blow dryer if needed. Then remove glue with the 50/50 Alcohol and water mixture. The goal is to have your skis squeaky clean with no oils, wax, glues or residues. Clean the skis with Windex then your 50/50 Alcohol and water mixture again. Remember (Squeaky Clean)

1. Hold your graphic over the top of the ski to place your graphic for position.

2. Tape across center (hinge).

3. Lift up left side hold vinyl in hand, then pull off the paper to the tape hinge. Cut the paper so you have the vinyl in your hand. Squeegee from the center out to the end of the ski.

4. Repeat step 3 for second half of ski.

5. Use a single edge razor or exacto blade to trim around the ski. Just ride the edge of the ski as a guide. Use caution not to slice into ski edge. Try to ensure that there are no overhangs left as this could lead to slight edge peel. ***Hint: When you are running around your ski with a blade, be careful of your edges as they are very sharp.

**YOUR EDGES SHOULD
LOOK LIKE THIS:**



6. Apply hair dryer to entire surface and edges of ski until it feels warm to the touch. Apply pressure again, allow ski to cool and then check adhesion around edges for a tight seal. Trim the areas that are not stuck down.

7. Feel for the binding holes, make a single slice and re-install your bindings.

Then repeat above steps for 2nd ski.

8. Feel free to call us if you have any questions while installing 586.239-8389

IMPORTANT

When trimming, trim inside edge as to not leave any over hanging edges.

The snow can catch on and tear the boardwrap.



Finished Product!

